



小童可調較日期款式

 SKETTO OCTOPUS WATCHES 八達通手錶 User Manual 使用說明  小童 Child  Sketto Limited 八達通錶  5600 5570  www.sketto.com.hk  sketto.limited 地址:荳灣西樓角路1-17號新領域廣場12樓1203室 電話:3520 0707	保用條款： 保用期：由購買日計起一年內並須出示購買收據。 SKETTO LIMITED茲證明此產品已通過嚴格之品質檢定。於保用期內如機能上有任何失常，可獲免費維修或更換；但不適用於更換電池、錶殼、錶帶因不適當處理、自行維修、改裝、游泳或意外所造成的損壞。若本公司決定為客戶更換新錶，該新錶將不附有任何儲值。於維修過程中影響到八達通內之儲值，SKETTO LIMITED概不負責。 Conditions of Warranty: Warranty Period: Within one year of the date of purchase when accompanied by the purchase receipt. SKETTO LIMITED certifies that this product has passed stringent quality check, warrants that the Company will repair or replace the watch free of charge if the watch malfunctions within the warranty period. The warranty is not applicable to the replacement of battery, case, glass, strap or any damage caused by improper treatment, modification, use in water, swimming or an accident. If a new watch is replaced, this new watch will have no initial stored value. SKETTO LIMITED cannot guarantee this product for defects or damage that occurs due to unusual circumstances or abusive force.	「小童八達通手錶」之條款及細則： 1.此八達通為根據「八達通發卡條款」發行之「銷售版八達通」（發卡條款可於八達通網站 www.octopus.com.hk 下載）。 2.此八達通功能與普通小童八達通無異，只適用於年齡介乎3至11歲之小童。 3.此八達通儲值額為零，使用前請先增值。 4.此八達通不設按金及不能退還。 5.如八達通儲值額為零或負數，該八達通即不能使用，直至增值為止。 6.此八達通的有效期為包裝上的印刷年期起計7年。往後八達通卡有限公司可延長此八達通的有效使用期或公佈註銷八達通功能的日期而毋須作出賠償。 Terms & Conditions for “Child Octopus Watch”: 1.This <i>Octopus</i> is designated as a “<i>Sold Octopus</i>” and is subject to the “Conditions of Issue of Octopus” (downloadable from Octopus website at www.octopus.com.hk, dispatched or displayed at designated transport stations). 2.The <i>Octopus</i> functions of this watch are the same as a normal Child <i>Octopus</i>. It may only be used by a child aged 3-11. 3.This <i>Octopus</i> has no initial stored value, please add value before use. 4.This <i>Octopus</i> has no deposit and is non-returnable. 5.If the value on your <i>Octopus</i> is zero or negative, it cannot be	used until it is reloaded. 6.This <i>Octopus</i> has a validity period of 7 years from the year of manufacture printed on the packaging and thereafter Octopus Cards Limited may at its discretion extend the validity period or announce a date on which the Octopus function shall be disabled without compensation. 「小童八達通手錶」實用小貼士： 1.申請某些八達通服務時需要八達通號碼。它通常印在八達通卡/配飾的背面。使用前請先移除包裝物料。 2.持有人可於各認可八達通增值服務供應商 (八達通增值機除外) 以現金增值，或透過八達通App增值，最高金額為\$3,000。 3.使用時請將此八達通拍向八達通讀寫器，直至聽到「嘟」聲及出現交易完成及餘額的顯示，才將八達通移開。若因拍八達通太快而不能完成交易，請將該八達通再次拍向同一讀寫器。 4.成人/長者可使用此八達通自行申請八達通自動增值服務。有關八達通自動增值服務，詳情請參閱 www.octopus.com.hk/aavs 或致電申請熱線 2266 2338。 5.請記錄八達通號碼作日後參考。若八達通號碼未能辨認，八達通卡有限公司或不能退還餘額。 6.請勿同時將多於一張八達通或與其他非接觸式智能卡拍向八達通讀寫器。	7.請勿擅自改動八達通，包括：摺曲、塗寫、刮花、剪割，或貼上貼紙、相片或其他裝飾品等，否則，有關該八達通之交易將不獲承認，餘額也將不獲退還。 Useful Tips for Using “Child Octopus Watch”: 1.The Octopus number is required when applying for certain Octopus services. It is usually printed on the back of the Octopus card/ornament. Please be reminded to remove the packaging before use. 2.Holders may add value to their Octopus at all Octopus Authorised Add Value Service Providers (except Add Value Machines) with cash or via Octopus App up to a maximum of \$3,000. 3.Place your Octopus steadily over an Octopus reader, hold and wait until you hear a “Dood” sound and there is an indication that the transaction is completed and the remaining value is shown on the screen before removing your Octopus. If the transaction is incomplete because you hold your Octopus too quickly over a reader, please present it over the reader again. 4.Adult/Elder holders may use this Octopus to apply for the Octopus Automatic Add Value Service. Please visit www.octopus.com.hk/aavs or call the application hotline 2266 2338 for details of the Octopus Automatic Add Value Service. 5.Please record your Octopus number for future reference. If the Octopus number cannot be identified, Octopus Cards Limited may not be able to refund the remaining stored value on the Octopus.	6.Do not hold more than one Octopus, or an Octopus with another contactless smartcard, over an Octopus reader at one time. 7.Do not tamper with your <i>Octopus</i>, such as bending, writing on, scratching, cutting, or pasting stickers, photos or accessories on it, otherwise, transactions will be not honoured and remaining stored value will not be refunded. SKETTO LIMITED 顧客服務熱線：3520 0707 SKETTO LIMITED Customer Service Hotline: 3520 0707 八達通卡有限公司牌照號碼：SVF0001 Octopus Cards Limited Licence Number: SVF0001 印刷年份：2024 Year of Manufacture: 2024	維修中心：荳灣西樓角路1-17號新領域廣場12樓1203室 (請先致電預約) Repair Service Center: Unit 03, 12/F, Grand City Plaza, 1-17 Sai Lau Kok Road, Tsuen Wan. (Please make appointment first) 維修時間 Servicing times: 星期一至星期四 10:00am - 12:00pm, 2:00pm - 5:00pm 星期六、日及公眾假期休息。 *敬請先致電 3520 0707預約* Monday & Thursday 10:00am - 12:00pm, 2:00pm - 5:00pm Saturday/Sunday & Public holidays closed. Please call 3520 0707 to make an appointment in advance.	 時針 Hour hand 分針 Minute hand 日期 Date 錶冠的正常位置 Normal position 秒針 Second hand 位置1 1st position 位置2 2nd position 位置1 1st position	日期及時間設定 Date & Time Setting  1. 把錶冠拉出至位置1,順時針方向旋轉調整日期。 Pull the crown out to the 1st position. Turn the crown clockwise to set Date. 2. 把錶冠拉出至位置2,逆時針方向旋轉錶冠設定時針和分針。 Pull the crown out to the 2nd position. Turn the crown anti-clockwise to set hour and minute hands. 3. 完成時間設定後將錶冠按回至正常位置。 After setting the time, push the crown back to the normal position.
---	---	--	--	---	--	--	--	---